What is the RAA100 configuration setting "Gauge Resistance, + to sender" and "Gauge Resistance, - to sender"?

276 Mark Oslund July 17, 2015 RAA100 0 4.70K

If the RAA100's operating mode is set to "NMEA 2000 & Analog Gauge", then it is important to configure the RAA100 with the gauge's resistances in order for the RAA100 to operate correctly. Please refer to the RAA100 User's Manual for a detailed description of measuring the gauge's resistance values.

Online URL: https://maretron.com/wp-content/phpkbv96/article.php?id=276