With regards to the DCM100, where should I connect the ring terminal of temperature sensor (part number TR3K)?

312 Mark Oslund June 2, 2014 DCM100 0 5.21K

You should connect the ring terminal on the Temperature Sensor to the negative terminal of the DC source being monitored.

Online URL: https://maretron.com/wp-content/phpkbv96/article.php?id=312